

Dedicated harness: KITCA1081

Universal harness: KITCA417N17

MODIFY KITCA1081 AS FOLLOWS:

- 1) Remove the 6-pin connector from the alarm wiring.
- 2) Connect the 6-pin connector RED wire to the BLACK wire going into pin 3 of the 4-pin connector.

POSITIVE, IGNITION, ENGINE IMMOBILIZER

Remove the ignition switch 4-pin connector and plug in the alarm wiring respective 4-pin connectors.

TURN INDICATORS (see diagram below, connectors are indicated by the arrows)

LH side: connect one of the alarm ORANGE wires to the WHITE-BLACK wire (beige in the counterpart) going into the LH side indicator 4-pin connector.

RH side: connect the other ORANGE wire to the BLUE wire (light blue in the counterpart) going into the RH side indicator 4-pin connector.

NB: The turn indicator connectors are located under the front fairing.

GROUND

Connect the alarm BROWN wire to the GREEN wire coming from one of the 2 turn indicators 4-pin connector.

POSITIVE

Connect the alarm RED wire to the RED-BLACK wire coming from the ignition switch 4-pin connector.

IGNITION

Connect the alarm YELLOW wire to the PINK-BLACK wire coming from the ignition switch 4-pin connector.

ENGINE IMMOBILIZER

Cut the PINK-BLACK wire coming from the ignition switch 4-pin connector; connect the alarm WHITE wire to the end going to the ignition switch and the grey wire to the other end. Attention: connect the YELLOW wire to the alarm WHITE wire.

TURN INDICATORS

With universal wire KITCA417N17 connect as detailed for KITCA1081.

GROUND

With universal harness KITCA417N17 connect as detailed for KITCA1081.

