

Rear Carrier Assembly Instruction (Joymax Z)

1) Remove the rear grips from vehicle.

2) Install rear carrier on rear grips with bolts (two pieces each side), through bottom and screw tight.

3) Together with carrier, assemble rear grips back on the vehicle and make sure both are fixed.

4) Put on the base plate and screw tight for top case usage.

