


PULLEY HOLDER


Adjusting hole

There are 2 adjusting holes for the minimum adjusting.

For the durable life of the tool and for securing the object in the minimum length of the belt, please don't pull the belt by violence.




Adjusting hole



1. Turn the clip to the left and loosen the belt when it is turned to the adequate position.

2. Put the object that you would like to fasten onto the inside of the belt.



3. Turn the clip to the right and tightly lock it with the rotary shaft when it is fastened.

4. The following operations are shown as the drawing.

